

Maintenance

TROUBLE SHOOTING TIPS

If your flameless candle does not come on despite following all instructions please try the following steps:

1. Make sure the switch is in the ON position on the bottom of the flameless candle.
2. Remove the pull tab from the battery compartment on the bottom of the flameless candle.
3. Check to see if the batteries are installed correctly or if they need replacement. If necessary, replace with 3 'AAA' batteries.

Warranty Information

1-YEAR LIMITED PRODUCT WARRANTY

This product is covered under a one year limited warranty. Fusion Products Ltd. warrants to the original purchaser that this product is free from defects in materials and workmanship for the period of one year warranty from date of purchase.

For Technical Support and/or Warranty inquiries please contact:

Fusion Products Ltd.

Monday to Friday

8:30-5:00 PM EST

2905 Argentia Road, Unit 2

Mississauga, Ontario L5N 8G6

Tel: 1-877-615-1378 Fax: (905) 812-3256

Email: sales@fusionproducts.ca



CERAMIC POT WITH FLAMELESS CANDLE



FUSION PRODUCTS LTD.

Model No. 20202

Contents

Overview	2
Getting Started	2
Operation	2-3
Replacing the Batteries	3
Maintenance	4
Warranty Information	4

Overview

This product is designed to the highest technical specifications and standards. It will supply years of maintenance free use. Please read these instructions thoroughly prior to installation, then store in a safe place for future reference. If at any time you are unclear about this product, or require further assistance please do not hesitate to contact our trained professionals operating the customer support line at 1-877-615-1378 Monday to Friday between the hours 8:30 AM to 5:00 PM Eastern Standard Time or email sales@fusionproducts.ca

Getting Started

Please do not throw away any packing material until all parts are verified as present.

Operation

FOR FIRST TIME USE:

Step 1:

Assemble handle to lantern body.

Step 2:

Remove the pull tab from the battery compartment on the bottom of the flameless candle.

Step 3:

Turn the switch on the bottom of the flameless candle to the ON position. Your flameless candle is now ready for use.

FOR NORMAL OPERATION:

For normal operation, turn the switch on the bottom of the flameless candle to the ON position. NOTE: The flameless candle has a 6/18 built in timer function. This will set the candle to be ON for 6 hours, and then OFF for 18 hours. Once the candle is in the ON position, the 6/18 timer is automatically activated.

FOR EXAMPLE: IF THE CANDLE IS INITIALLY TURNED ON AT 5:00 PM, IT WILL TURN OFF AUTOMATICALLY AT 11:00PM. THE FLAMELESS CANDLE WILL CONTINUE TO CYCLE LIKE THIS EACH DAY UNTIL YOU SWITCH IT TO THE OFF POSITION. ONCE TURNED ON AGAIN, A NEW 6/18 HOUR CYCLE WILL BEGIN.

To use the flameless candle as needed, turn the switch to the ON position and return to the OFF position once done.

REPLACING THE BATTERIES:

Step 1:

Turn the switch on the bottom of the flameless candle to OFF.

Step 2:

With a screwdriver, remove the screw securing the battery compartment cover on the bottom of the flameless candle.

Step 3:

Carefully remove the battery compartment cover.

Step 4:

Carefully remove the old batteries from the battery compartment.

Step 5:

Replace batteries with 3 'AAA' batteries, ensuring the correct polarity is observed.

Step 6:

Reassemble the unit by reversing the above procedure.

Step 7:

Return the switch to the ON position.

Warning:

Battery must be recycled or disposed of properly. The battery cannot be ingested. Do not mix old and new batteries. Do not mix alkaline, standard (carbon-zinc), or rechargeable (ni-cad, ni-mh, etc.) batteries.