

Trouble Shooting Tips

If your solar light does not come on at dusk despite following all instructions please try the following steps:

1. Make sure that the solar light is not affected by any other light source.
2. Ensure the solar light does not stand in the shade all day.
3. Check to see if the batteries are installed correctly.
4. If there is a protective film on the solar panel carefully remove this.

Care Information

1. Clean any dirt and debris from the solar panel. The panel cannot recharge if the light is obstructed. Use a soft cloth to clean the panel. Do not use abrasives or chemicals that might scratch or damage the UV coating.
2. In a region where snow and ice are likely and the light assembly is covered with snow for an extended period of time the batteries will require a recharge for at least 8 hours.

Warranty Information

1-YEAR LIMITED PRODUCT WARRANTY

This product is covered under a one year limited warranty. Fusion Products Ltd. warrants to the original purchaser that this product is free from defects in materials and workmanship for the period of one year warranty from date of purchase.

**For Technical Support and/or Warranty inquiries
please contact:**

Fusion Products Ltd.

Monday to Friday

8:30-5:00 PM EST

2905 Argentia Road, Unit 2,3

Mississauga, Ontario L5N 8G6

Tel: 1-877-615-1378 Fax: (905) 812-3256

Email: sales@fusionproducts.ca

FUSION™

2 SOLAR COACH STYLE LAMP POSTS



FUSION PRODUCTS LTD.

Model No. 24290

Contents

| | |
|------------------------------|-----------|
| Overview | see below |
| Getting Started | 1 |
| About Your Solar Light | 1 |
| Important | 1 |
| Schematic Diagram | 2 |
| Operation | 3 |
| Assembly & Installation..... | 3-4 |
| Battery Replacement | 5 |
| Trouble Shooting Tips | 6 |
| Care Information | 6 |
| Warranty Information | 6 |

Overview

This product is designed to the highest technical specifications and standards. It will supply years of maintenance free use. Please read these instructions thoroughly prior to installation, then store in a safe place for future reference. If at any time you are unclear about this product, or require further assistance please do not hesitate to contact our trained professionals operating the customer support line at 1-877-615-1378 Monday to Friday between the hours 8:30 AM to 5:00 PM Eastern Standard Time or email sales@fusionproducts.ca

Battery Replacement

STEP 1:

Turn the switch to the <OFF> position (Figure 7).

STEP 2:

Remove the screws (4) underneath the perimeter of the solar top/housing. Carefully lift the solar housing away from the lantern head (Figure 8).

STEP 3:

Remove the screws (4) from the battery compartment cover under the solar housing.

STEP 4:

Carefully separate the battery compartment cover from the solar housing; being sure not to detach any of the connected wires (Figure 9).

STEP 5:

Replace the battery with an equivalent new solar rechargeable battery, ensuring the correct polarity is observed (Figure 9).

STEP 6:

Reassemble the unit by reversing the above procedure.

STEP 7:

Allow the unit to charge for up to 2 days in the <OFF> position. Once fully charged turn the switch to the <ON> position and the solar light will turn on automatically when it becomes dark.

Caution: Rechargeable batteries contain lithium and must be recycled or disposed of properly. Do not mix old and new batteries. Do not mix alkaline, standard (carbon-zinc), or rechargeable batteries. Do not dispose of batteries in fire. Batteries may explode or leak.

Figure 7




Figure 8





Figure 9



Installation (Hanging Lantern)

STEP 1:

Follow Steps 1- 6 in the Standard Installation.

STEP 2:

Secure hanging bracket (G) to top pole section with screw until secure (Figure 5).

STEP 3:

Hang lantern head assembly onto hanging bracket (Figure 5, 6).

Figure 5




Figure 6



Getting Started

Please do not throw away any packing material until all parts are verified as present.

About Your Solar Light

During the day your solar panel will convert the sun's light and/or UV rays into electrical power that will charge the rechargeable battery. When it becomes dark, the solar light will turn on using the power stored on the rechargeable battery as it will detect no day light. The units light output strength and time depends on how many hours and how much sunlight and/or UV rays your panel absorbs throughout the day.

For maximum output place the solar panel in an area where there is direct sunlight for at least 8 hours in a given day. Do not install your solar light in a shaded area. The selected location should not be near night time light sources such as; porch lights, street lights or pool lights as these may cause the solar light to turn off prematurely.

Important

- Fully charge the battery before first use. Charge under direct sunlight in the <OFF> position for 2 days.
- For best results, locate your solar lamp in a position where it can get direct sunlight on the solar panel and generally free from cover and shade.
- Keep your solar lights away from other night-time light sources, such as streetlights.
- Make sure the solar panels are not covered by dust, snow and debris. Clean it with a soft damp cloth or paper towel periodically. Avoid the use of abrasive cleaning agents.
- Use only rechargeable batteries for your solar lights. Replace with a new battery of the same size each year for optimum performance.
- The performance of the solar light will vary with the time of year. It will deliver more light when it has had a full day in the sun rather than a day in overcast weather.

Schematic Diagram

Figure 1
Standard





Figure 2
Hanging



Operation

For First Time Use:

STEP 1:


Fully charge the battery before first use. Charge under direct sunlight in the <OFF> position for 2 days.

STEP 2: Locate the ON/OFF switch on the outer perimeter of the solar housing (Figure 3).

STEP 3:

For daily operation, place the ON/OFF switch in the <ON> position. Your solar light will automatically turn on once it gets dark.

Figure 3



Assembly & Installation

You have the option for each lamp post to assemble as per Figure 1 (standard), or Figure 2 (hanging lantern).

Installation (Standard)

STEP 1:

Select a suitable location to install and secure the lamp post base (Figure 4).

STEP 2:

Press pole section (C) onto base (F) until secure.

STEP 3:

Press pole adapter (D) into pole (C) until secure.

STEP 4:

Press pole section (C) onto pole adapter (D) until secure.

STEP 5:

Press center pole adapter (E) into pole (C) until secure.

STEP 6:

Repeat step 4 until desired height is achieved.

STEP 7:

Press lantern head assembly (A & B) onto top pole section until secure.

Figure 4

